



REVISION

ROTE

REVISION

ROTE

All levels and dimensions to be checked onsite. Any discrepancies to be reported to cooney. Architects. Do not scale off this drawing. Use figured dimension only.

This drawing is to be read in conjunction with all other revision feerence with all associated Engineers drawings.

Trevision

Trevisi